

- Insert CD
- Double-click (DC) on 170927\_DMT-DDv2.00\_win10
- DC on setup\_win10
- DC on en
- DC on DMT-DDSetup\_ms

← → ~ ↑ 📙 « setup_win10 → en			ٽ ~	✓ ひ Search en		
🕹 Quick access		Name	Date	modified	Туре	Size
		🔂 DMT-DDSetup_ms	9/15/	2017 11:30 AM	Windows Installer	6,005 KB
Desktop		read_me	9/27/	2017 11:40 AM	Text Document	2 KB
Downloads	R	🐻 setup	9/15/	2017 11:30 AM	Application	371 KB
Documents	*					
Pictures	*					
👌 Music						
Videos						
\land OneDrive						
💻 This PC						
🔜 USB Drive (D:)						
DMC Touch Tre	eiber					
	DMC_					
DMT-DD_v2.0	00_wi					



- DMT-DD Setup Wizard opens:
- —> Next —> I Agree —> Next —> Next



After installation of touch software: DC on DMT-DD icon Select **Device Addition** and install USB Port (USB Port > Install).



After installation of USB Port reboot PC manually

After restart DC on icon DMT-DD

Select Basic Settings (2. button left side)

Define rotation of touch under tab ,<u>Software Setting</u>':

- Choose 0 for 15" touch
- Choose 180 for 17" and 19" touches

## Finally click on Entry.

Touch Screen Properties	[	) ×
Device Addition	Device Select (USB)ID:1	
Basic Setting	Software Setting Touch Input Setting Touch Sound Hardware Information Configuration	n File
Touch Setting	Software Setting Rotation [degree] O 0 O 90 O 180 O 270 D Auto Function	
Mouse Setting	Entry	
Tool Setting	-Calibrate	
	4Point 9Point  None 15 30	60
	Check Reset EEPROM	
Exit	EEPROM is not found.	

## Click on tab <u>Touch Input Setting</u> (>> next page)



Touch Data Mode: Select Hybrid Mode Click on Entry

## Click on 3rd button left (**Touch Setting**) ,Tablet PC Setting' - Click on Open

Touch Screen Properties		-		×
Device Addition	TabletPC Setting			
Basic Setting	Configure each setting on the opened screen.		Open	]
Touch Setting	Pen and Touch Open the touch-input setting screen. Configure each setting on the opened screen.		Open	
Mouse Setting				
Tool Setting				
Exit				

A new windows is popping up. Click on ,Calibrate'

💐 Tabl	et PC Setti	ngs		×		
Display Cont	Other					
Conf disp	Configure your pen and touch displays.					
Disp	lay option	5				
Disp	lay:	1. 1280x1024		$\sim$		
Details:		Single Touch Support				
			- Rese	et		
Choo <u>Go to</u>	ose the ord	er in which your scr on	een rotates.			
		ОК	Cancel	<u>A</u> pply		

In total 16 crosses will be prompted, one after the other.

These must be touched as exactly as possible (if necessary, use a blunt pin side).

This concludes the driver installation and calibration.

Contact us for further questions: UTICOR Automation GmbH Hanns-Martin-Schleyer-Str. 34 47877 Willich Tel.: +49-(0)2154-89-1964-0 Fax: +49-(0)2154-89-1964-9

> Web.: www.uticor.de Email: info@uticor.de

